Step by Step Instructions



1. Prep Your Garment

Preheat your iron to the temperature setting recommended for your garment fabric (preferred temperature is cotton / linen setting with steam OFF and the water reservoir empty). Work on a hard, flat surface, not a padded ironing board. Pre-pressing your garment is suggested to start with a wrinkle-free canvas.



2. Position Your Design

Position your transfer in the desired location and make sure it is flat before pressing.



3. Press & Peel

Cover the transfer with the provided parchment paper and press straight down with firm pressure for **~15-20 Seconds**. Press in small circular motions across the entire design so every part of the design, including edges and corners, gets continuous heat.

Wait a few seconds (or longer) and peel. If any part of the design lifts while peeling, lay the transfer back down and press again with firm pressure for another 10–15 seconds.



4. Do a Final Press

Important: A final press is imperative to confirm a superior adhesion.

With the film fully peeled off, cover the design with parchment paper and press again for **~15-20 Sec**. This locks the ink into the fibers and greatly improves durability and softness.